



AMS-TTCS		Page	13	
		OF	25	
Title	Accumulator Assembly Incoming & Outgoing Inspection Procedure	ISSUE	1.0	


## 8. TEST PROCEDURE SHEET

	Accumulator incoming & outgoing inspection		company: AIDC	date: 30/12/2008		
	Fill in by hand.		engineer: Raki Huang	location: J2303		
Step	Action	Monitoring	Value	Result	Comment	✓
1.	Record test equipment in appendix 1					
2.	Record inspection type (is it incoming or outgoing?)		Incoming /outgoing	Incoming		✓
3.	Component comes from	origin		SYSU		✓
4.	Component goes to	destination		AIDC		✓
5.	Part number					

AMS-TTCS		Page	14	
		OF	25	
Title	Accumulator Assembly Incoming & Outgoing Inspection Procedure	ISSUE	1.0	


	Accumulator incoming & outgoing inspection		company:		date:	
	Fill in by hand.		engineer:		location:	
Step	Action	Monitoring	Value	Result	Comment	✓
6.	Serial number					
7.	Record model type		QM /FM	FM1	Used for TTCB-QM box afterwards	✓
8.	Visual inspection, unaided eye, look at outer surface for - scratches - dents	scratches dents fitting				
9.	Take pictures of the accumulator from all sides					
10.	Accumulator dimension check (Write the measured values in the Appendix drawings)		TTCB0100_2; ET5998-07; TTCB0100_3			
11.	Clamp dimension check (Write the measured values in the Appendix drawings)		TTCB010201			
12.	Slide dimension check (Write the measured values in the Appendix drawings)		TTCB010501			

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS		Page	15	
		OF	25	
Title	Accumulator Assembly Incoming & Outgoing Inspection Procedure	ISSUE	1.0	


Accumulator incoming & outgoing inspection			company:		date:	
Fill in by hand.			engineer:		location:	
Step	Action	Monitoring	Value	Result	Comment	✓
13.	Check the bolt types					
14.	Check the torque of Clamp Bracket-Collar bolts (NAS1351N08-14)		22.8 In*lbf -26.9 In*lbf			
15.	Check the torque of Pipe Fix-Clamp bolts (NAS1351N06-10)		13.3 In*lbf -15.7 In*lbf			
16.	Check the torque of Press-Saddle bolts (NAS1351N08-12)		22.8 In*lbf -26.9 In*lbf			
17.	Check the heater resistance					
	1. Resistance of FAC_a	Resistance	20.9±1 Ω	21.9 Ω		✓
	2. Resistance of FAC_b	Resistance	20.9±2 Ω	21.6 Ω		✓
18.	Check the electric insulation of heater					
	1. Electric insulation of FAC_a	Resistance	>20Mohm	OPEN		✓

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS		Page	16	
		OF	25	
Title	Accumulator Assembly Incoming & Outgoing Inspection Procedure	ISSUE	1.0	


	Accumulator incoming & outgoing inspection		company:		date:	
	Fill in by hand.		engineer:		location:	
Step	Action	Monitoring	Value	Result	Co'mment	√
	2. Electric insulation of FAC_b	Resistance	>20Mohm	OPEN		√
19.	Check the Peltier element resistance					
	1. Resistance of Peltier element 1	Resistance	3.4±10hm@25℃	46Ω		√
	2. Resistance of Peltier element 2	Resistance	3.4±10hm@25℃	47Ω		√
	3. Resistance of Peltier element 3	Resistance	3.4±10hm@25℃	46Ω		√
	4. Resistance of Peltier element 4	Resistance	3.4±10hm@25℃	45Ω		√
20.	Check the electric insulation of Peltier element					
	1. Electric insulation of Peltier element 1	Resistance	>20Mohm	OPEN		√
	2. Electric insulation of Peltier element 2	Resistance	>20Mohm	OPEN		√

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

AMS-TTCS		Page	17	
		OF	25	
Title	Accumulator Assembly Incoming & Outgoing Inspection Procedure	ISSUE	1.0	


	<b>Accumulator incoming &amp; outgoing inspection</b>		company:		date:	
	Fill in by hand.		engineer:		location:	
Step	Action	Monitoring	Value	Result	Comment	✓
	3. Electric insulation of Peltier element 3	Resistance	>20Mohm	OPEN		✓
	4. Electric insulation of Peltier element 4	Resistance	>20Mohm	OPEN		✓
21.	<b>He leak test:</b> Measure equipment background level (put cap on tester, without test item being connected)	Background Leak Rate	$<2*10^{-10}$ mbar.l/s	$<1*10^{-10}$ mbar.l/s		✓
22.	<b>He leak test:</b> Connect test item and measure leak rate value without spraying helium	Leak Rate	$<2*10^{-10}$ mbar.l/s	$<1*10^{-10}$ mbar.l/s		✓
23.	<b>He leak test:</b> Connect test item and cover it with a plastic bag and measure and record the leak rate value when the plastic bag is filled with helium	Leak Rate	$<1*10^{-9}$ mbar.l/s	$<1*10^{-10}$ mbar.l/s		✓
24.	<b>Disconnect the accumulator liquid pipe from the leak tester</b>					✓
25.	<b>He leak test:</b> Measure equipment background level (put cap on tester, without test item being connected)	Background Leak Rate	$<2*10^{-10}$ mbar.l/s	$<1*10^{-10}$ mbar.l/s		✓
26.	<b>He leak test:</b> Connect test item and measure leak rate value without spraying helium	Leak Rate	$<2*10^{-10}$ mbar.l/s	$<1*10^{-10}$ mbar.l/s		✓

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.


AMS-TTCS		Page	18	
		OF	25	
Title	Accumulator Assembly Incoming & Outgoing Inspection Procedure	ISSUE	1.0	

	Accumulator incoming & outgoing inspection		company:		date:	
	Fill in by hand.		engineer:		location:	
Step	Action	Monitoring	Value	Result	Comment	✓
27.	He leak test: Connect test item and cover it with a plastic bag and measure and record the leak rate value when the plastic bag is filled with helium	Leak Rate	$<1 \times 10^{-9}$ mbar.l/s	$<1 \times 10^{-10}$ mbar.l/s		✓
28.	Disconnect the Peltier pipe from the leak tester					✓
	End of sheet					

10/01/2009  
 Additional check  
 during fit checking  
 F71 Primary box  
 (Afterwards used for QM box)

AMS-TTCS		Page	15	
		OF	25	
Title	Accumulator Assembly Incoming & Outgoing Inspection Procedure	ISSUE	1.0	


	Accumulator incoming & outgoing inspection		company: ALDC		date: 10/01/2009	
	Fill in by hand.		engineer: Raki Huang		location: J2303	
Step	Action	Monitoring	Value	Result	Comment	✓
13.	Check the bolt types					
14.	Check the torque of Clamp Bracket-Collar bolts (NAS1351N08-14)		22.8 In*lb -26.9 In*lb			
15.	Check the torque of Pipe Fix-Clamp bolts (NAS1351N06-10)		13.3 In*lb -15.7 In*lb			
16.	Check the torque of Press-Saddle bolts (NAS1351N08-12)		22.8 In*lb -26.9 In*lb			
17.	Check the heater resistance					
	1. Resistance of FAC_a	Resistance	20.9 ± 1 Ω	22.4 Ω		
	2. Resistance of FAC_b	Resistance	20.9 ± 2 Ω	22.1 Ω		
18.	Check the electric insulation of heater					
	1. Electric insulation of FAC_a	Resistance	>20Mohm	Over 25MΩ		

AMS-TTCS		Page	16	
		OF	25	
Title	Accumulator Assembly Incoming & Outgoing Inspection Procedure	ISSUE	1.0	

	Accumulator incoming & outgoing inspection		company:		date:	
	Fill in by hand.		engineer:		location:	
Step	Action	Monitoring	Value	Result	Comment	√
	2. Electric insulation of FAC_b	Resistance	>20Mohm	Over 17 M.Ω		
19.	Check the Peltier element resistance					
	1. Resistance of Peltier element 1	Resistance	3.4±1Ohm@25℃	4.4 Ω		
	2. Resistance of Peltier element 2	Resistance	3.4±1Ohm@25℃	5.2 Ω		
	3. Resistance of Peltier element 3	Resistance	3.4±1Ohm@25℃	5.3 Ω		
	4. Resistance of Peltier element 4	Resistance	3.4±1Ohm@25℃	4.3 Ω		
20.	Check the electric insulation of Peltier element					
	1. Electric insulation of Peltier element 1	Resistance	>20Mohm	OPEN		
	2. Electric insulation of Peltier element 2	Resistance	>20Mohm	OPEN		


No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.



AMS-TTCS		Page	17	
		OF	25	
Title	Accumulator Assembly Incoming & Outgoing Inspection Procedure	ISSUE	1.0	

	<b>Accumulator incoming &amp; outgoing inspection</b>		company:		date:	
	Fill in by hand.		engineer:		location:	
Step	Action	Monitoring	Value	Result	Comment	√
	3. Electric insulation of Peltier element 3	Resistance	>20Mohm	OPEN		
	4. Electric insulation of Peltier element 4	Resistance	>20Mohm	OPEN		
21.	<b>He leak test:</b> Measure equipment background level (put cap on tester, without test item being connected)	Background Leak Rate	$<2*10^{-10}$ mbar.l/s			
22.	<b>He leak test:</b> Connect test item and measure leak rate value without spraying helium	Leak Rate	$<2*10^{-10}$ mbar.l/s			
23.	<b>He leak test:</b> Connect test item and cover it with a plastic bag and measure and record the leak rate value when the plastic bag is filled with helium	Leak Rate	$<1*10^{-9}$ mbar.l/s			
24.	<b>Disconnect the accumulator liquid pipe from the leak tester</b>					
25.	<b>He leak test:</b> Measure equipment background level (put cap on tester, without test item being connected)	Background Leak Rate	$<2*10^{-10}$ mbar.l/s			
26.	<b>He leak test:</b> Connect test item and measure leak rate value without spraying helium	Leak Rate	$<2*10^{-10}$ mbar.l/s			

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.

<b>AMS-TTCS</b>		Page	<b>19</b>	
		OF	<b>25</b>	
Title	Accumulator Assembly Incoming & Outgoing Inspection Procedure	ISSUE	1.0	

## 9. APPENDIX 1 TEST EQUIPMENT

Test equipment	Manufacturer and type	Calibration / functional check	
		Date	Next Date
Multimeter	Agilent 34401A	07/24/2008	07/24/2009

## 10. APPENDIX 2 ACCUMULATOR DRAWINGS

No part of this document may be reproduced and/or disclosed, in any form or by any means, without the prior written permission of SUN YAT-SEN UNIVERSITY.